



RENEGADE PRO-SERIES DIFFERENTIAL STAND

REQUIRED TOOLS

- 7/16" wrench/socket
- 1/2" wrench/socket
- Ratchet

BEFORE YOU BEGIN

- Verify all components are present before assembly.
- Casters and ratchet straps come pre-installed from factory.
- Assemble on a flat, stable surface.

ASSEMBLY

STEP 1 — Install Adjustable Support Tower

Slide the adjustable upright support tower onto the lower subframe with the axle saddle plate facing outward.



STEP 2 — Install Fixed Support Tower

Insert the male end of the fixed support tower into the female side of the lower subframe until the mounting holes align.



STEP 3 — Install Subframe Hardware

Using the supplied Grade 8 hardware kit, locate:

- (2) 5/16" x 2" bolts
- washers
- lock nuts

Install one bolt per side through the aligned subframe mounting holes. Tighten securely.

STEP 4 — Install Tray Bases

Using:

- (8) 1/4" x 2" bolts
- washers
- lock nuts

Attach the black tray bases to the support towers with trays facing outward.

Do not fully tighten hardware until all bolts are installed.



STEP 5 — Install Tool Trays

Using:

- (6) 1/4" x 3/4" bolts
- washers
- lock nuts

Align and install the yellow Renegade tool trays onto the tray bases. Tighten all hardware securely.



FINAL INSPECTION

Before use:

- Verify all hardware is tightened securely.
- Confirm support towers move freely and lock correctly.
- Inspect ratchet straps for proper routing and operation.
- Lock caster brakes before loading any axle assembly.



SAFETY INFORMATION

- Use only on flat, stable surfaces.
- Do not exceed rated load capacity.
- Always secure axle assemblies with supplied straps.
- Inspect stand and hardware before each use.
- Keep hands clear of pinch points during adjustment.

www.renegadepformanceproducts.com