



Drivetrain First Aid kit

Part No. RPP-90-200

The Renegade Drivetrain First Aid Kit gives off-roaders the critical parts and tools needed to repair driveshaft and axle U-joints right on the trail, so you can get rolling again instead of calling for a tow.



Trailside Safety:

- Safely support the vehicle
- Remove all broken drivetrain components



DRIVETRAIN FIRST AID KIT KIT CONTENTS:

Item:

Qty:

Canvas Trail Bag	1
Compact U-joint Clip Tool	1
Compact U-joint Clip Pliers	1
Front Axle U-joint (760X Size) YJ,TJ,LJ,XJ,ZJ	1
Front Axle U-Joint (7166X Size) JK / JL / JT	1
1310 Greaseable Driveline U-Joint (153X Size)	1
1350 Greaseable Driveline U-Joint (178X Size)	1
1310 Driveline U-Bolt Kit	1
1350 Driveline U-Bolt Kit	1
1310 Driveline Strap Kit	1
1310 5/16" CV Driveshaft Bolts	2
1/2"-20 Rear wheel Studs	2
1/2"-20 Front Wheel Studs	2

Warranty Information:

All merchandise manufactured by Renegade Performance Products is guaranteed against defects in material and workmanship for a period of 2-Years from the original date of purchase. Renegade Performance Products will not warranty any products that have been modified or where the product became defective due to improper installation, improper use or any other damages caused by defects in the product. Any request for warranty assistance will require your original receipt or acceptable proof of purchase. Renegade Performance Products liability is limited to the cost of repair or replacement of the product. All warranty items will be viewed and acted upon at the discretion of Renegade Performance Products.

Thank you very much for purchasing a Renegade Performance Product.



921 N.Harbor Blvd #101 La Habra, CA 90631 | 866-790-4130

www.renegadepformanceproducts.com